

PHASE INDICATOR KEW 8031/8031F

Simple operation and ruggedness. Check of open phase and phase sequence are possible in one unit.







Long selling models were renewed with the design and the measurement category!

Two Functions in One Unit

Presence of open phase can be checked by the lamps, and the phase sequence can be indicated by the rotating disk.

High Reliability

Wide measuring range for 3-phase installations from 110V to 600V. Sealed against dust ensures the trouble-free performance.

Battery-free tester

Connect the clips to the terminals. Press the push switch button. PRESS TO WEST TEST OF THE PRESS TO WEST TO WES

Two functions in one unit

Phase check with three lamps.

OK open phase





Sequence check with rotating disk.

Positive phase (clockwise)

Reversed phase (counter-clockwise)





KEW 8031/8031F Specifications

	KEW 8031 (Standard Type)	KEW 8031 (CE Type)	KEW 8031F (Fuse incorporated)
Appearance			
Operational voltage	110 - 600V AC (50/60Hz)		
Time limit for continuous	>500V: within 5 minutes		
Fuse	-		0.5A/600V (F)
Applicable standards	– *non compliant with CE	IEC 61010-1 CAT IV 300V, CAT Ⅲ 600V Pollution degree 2	
Dimensions	$106(L) \times 75(W) \times 40(D)mm$		
Weight	350g approx.		
Cord	1.5m (R: red S: white T: blue)		
Accessories	9029 (Carrying Case) Instruction manual		8923 (Fuse[0.5A/250V])* 9094 (Carrying Case) Instruction Manual

Accessories





Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

*included

Cosinus Messtechnik GmbH Rotwandweg 4 D-82024 Taufkirchen Tel 089-665594-0 Fax 089-665594-30 e-Mail: office@cosinus.de Internet: www.cosinus.de