



- For calibration of PATs and VDE 0701 testers
- Earth bond range 18Ω to $20m\Omega$
- Earth bond currents up to 50A AC
- Load test currents up to 13A AC
- V & I displayed on integral LCD digital meter
- · Safety interlock feature
- Battery operation (>200 hrs between charges)
- Portable and robust carrying case

DESCRIPTION

A precision calibrator designed to provide rapid high accuracy calibration of portable appliance testers and insulation/continuity testers. The 5080 has calibration functions for earth bond, insulation, leakage, touch leakage, and load test. Housed in a robust safety case the 5080 is easily portable and ideal for field calibration work. It is battery powered, which ensures isolation and prevents inaccuracies due to stray leakage. Features include safety interlock that prevents

contact with earth bond studs during insulation and leakage tests, and an LCD display for voltage and current.

SPECIFICATIONS

Earth Bond - Calibrated low value resistive loads

 $20m\Omega,\,accuracy\,5\%.\,190m\Omega,\,210m\Omega,\,950m\Omega,\,1.050m\Omega,\,1.08\Omega,\,2\Omega,\,10\Omega,\,18\Omega,\,accuracy\,\,1\%$

Open circuit voltage measurement Range: 0 to 20V. Accuracy: 0.25% of full scale

Insulation - Calibrated high value resistive loads

95kΩ, 105kΩ, 500kΩ, 950kΩ, 1.05MΩ, 5MΩ, 10MΩ, accuracy 0.1%. 20MΩ, 50MΩ, 100MΩ, accuracy 1.0%

Leakage - Resistive loads for leakage current

Nominal leakage currents at 230V AC of 0.5, 1, 2, 5, 10, 15mA

Touch Leakage - Constant current source for touch leakage meters

Current ______1.9mA AC 50 +/-5 Hz, into 2K2 maximum load resistance

Load Test - Connection of external load via a IEC connector

ORDERING INFORMATION

5080	. P A	TCAL	. – 1	Port	able	A	plianc	e Teste	r Calibrator
	_					_			

C188 Factory Calibration Certificate (NPL)
C135 UKAS Calibration Certificate (17025)

Due to continuous development Time Electronics reserves the right to change specifications without prior notice.

